


4


A-b

A TUNER AMP UNIT



Pin No.	Pin Name	I/O	Format	Function and Operation
133	P7AVSS			GND for port 7
134	P7AVDD			VDD for port 7
135	AVSS			A/D converter GND
136	SL	I		Signal level input
137-140	NC			Not used
141	MODELAD	I		Model select terminal
142	KEYAD	I		Wired remote control AD input
143	NC			Not used
144	AVREF0			A/D converter reference voltage


PN5011A



Format	Meaning
C	CMOS
N	Nch open drain

BA4918-V12

● Block Diagram



● Pin Layout

